


Organisasi Sistem Komputer

OSK 8 – Aritmatika Komputer

Muh. Izzuddin Mahali, M.Cs.





Arithmetic & Logic Unit



- ❖ Does the calculations
- ❖ Everything else in the computer is there to service this unit
- ❖ Handles integers
- ❖ May handle floating point (real) numbers
- ❖ May be separate FPU (maths co-processor)
- ❖ May be on chip separate FPU (486DX +)




ALU Inputs and Outputs



Integer Representation



- ❖ Only have 0 & 1 to represent everything
- ❖ Positive numbers stored in binary
 - e.g. $41 = 00101001$
- ❖ No minus sign
- ❖ No period
- ❖ Sign-Magnitude
- ❖ Two's compliment



- ❖ Left most bit is sign bit
- ❖ 0 means positive
- ❖ 1 means negative
- ❖ $+18 = 00010010$
- ❖ $-18 = 10010010$
- ❖ Problems
 - Need to consider both sign and magnitude in arithmetic
 - Two representations of zero (+0 and -0)



Two's Complement



$$\blacklozenge +3 = 00000011$$

$$\blacklozenge +2 = 00000010$$


$$\blacklozenge +1 = 00000001$$

$$\blacklozenge +0 = 00000000$$

$$\blacklozenge -1 = 11111111$$




$$\blacklozenge -2 = 11111110$$

$$\blacklozenge -3 = 11111101$$




- ❖ One representation of zero
- ❖ Arithmetic works easily (see later)
- ❖ Negating is fairly easy
 - $3 = 00000011$
 - Boolean complement gives 11111100
 - Add 1 to LSB 11111101

Geometric Depiction of Twos Complement Integers




Negation Special Case 1



- ❖ $0 =$ 00000000
- ❖ Bitwise not 11111111
- ❖ Add 1 to LSB +1
- ❖ Result 1 00000000
- ❖ Overflow is ignored, so:
- ❖ $-0 = 0 \checkmark$




Negation Special Case 2



- ❖ $-128 = 10000000$
- ❖ bitwise not 01111111
- ❖ Add 1 to LSB $+1$
- ❖ Result 10000000
- ❖ So:
- ❖ $-(-128) = -128$ X
- ❖ Monitor MSB (sign bit)
- ❖ It should change during negation



Range of Numbers



❖ 8 bit 2s compliment


- $+127 = 01111111 = 2^7 - 1$
- $-128 = 10000000 = -2^7$

❖ 16 bit 2s compliment

- $+32767 = 01111111 11111111 = 2^{15} - 1$
- $-32768 = 10000000 00000000 = -2^{15}$




Conversion Between Lengths



- ❖ Positive number pack with leading zeros
- ❖ $+18 = \quad\quad\quad 00010010$
- ❖ $+18 = 00000000\ 00010010$
- ❖ Negative numbers pack with leading ones
- ❖ $-18 = \quad\quad\quad 10010010$
- ❖ $-18 = 11111111\ 10010010$
- ❖ i.e. pack with MSB (sign bit)

Addition and Subtraction





- ❖ Normal binary addition
- ❖ Monitor sign bit for overflow

- ❖ Take twos compliment of subtrahend and add to minuend
 - i.e. $a - b = a + (-b)$

- ❖ So we only need addition and complement circuits




Hardware for Addition and Subtraction



OF = overflow bit

SW = Switch (select addition or subtraction)






- ❖ Complex
- ❖ Work out partial product for each digit
- ❖ Take care with place value (column)
- ❖ Add partial products



Multiplication Example



1011 Multiplicand (11 dec)

1101 Multiplier (13 dec)

1011 Partial products

0000 Note: if multiplier bit is 1 copy

1011 multiplicand (place value)



1011 otherwise zero

10001111 Product (143 dec)

Note: need double length result




Unsigned Binary Multiplication



(a) Block Diagram




Execution of Example



C	A	Q	M		
0	0000	1101	1011	Initial Values	
0	1011	1101	1011	Add	} First Cycle
0	0101	1110	1011	Shift	
0	0010	1111	1011	Shift	} Second Cycle
0	1101	1111	1011	Add	} Third Cycle
0	0110	1111	1011	Shift	
1	0001	1111	1011	Add	} Fourth Cycle
0	1000	1111	1011	Shift	




Flowchart for Unsigned Binary Multiplication



Product
in A, Q





Multiplying Negative Numbers




- ❖ This does not work!
- ❖ Solution 1
 - Convert to positive if required
 - Multiply as above
 - If signs were different, negate answer
- ❖ Solution 2
 - Booth's algorithm

Booth's Algorithm




Example of Booth's Algorithm



A	Q	Q ₋₁	M		
0000	0011	0	0111	Initial Values	
1001	0011	0	0111	A A - M } Shift	First Cycle
1100	1001	1	0111		
1110	0100	1	0111	Shift	} Second Cycle
0101	0100	1	0111		
0010	1010	0	0111	A A + M } Shift	Third Cycle
0001	0101	0	0111		
				Shift	} Fourth Cycle









- ❖ More complex than multiplication
- ❖ Negative numbers are really bad!
- ❖ Based on long division




Division of Unsigned Binary Integers




Division Algorithm



Example



A	Q	M = 0011
0000	0111	Initial value
0000	1110	Shift
1101		Subtract
0000	1110	Restore
0001	1100	Shift
1110		Subtract
0001	1100	Restore
0011	1000	Shift
0000		Subtract
0000	1001	Set $Q_0 = 1$
0001	0010	Shift
1110		Subtract
0001	0010	Restore



- ❖ Numbers with fractions
- ❖ Could be done in pure binary
 - $1001.1010 = 2^4 + 2^0 + 2^{-1} + 2^{-3} = 9.625$
- ❖ Where is the binary point?
- ❖ Fixed?
 - Very limited
- ❖ Moving?
 - How do you show where it is?







- ❖ \pm .significand $\times 2^{\text{exponent}}$
- ❖ Misnomer
- ❖ Point is actually fixed between sign bit and body of mantissa
- ❖ Exponent indicates place value (point position)

Sign bit	Biased Exponent	Significand or Mantissa
----------	-----------------	-------------------------



Floating Point Examples



(a) Format

0.11010001	2^{10100}	=	0	10010011	101000100000000000000000
-0.11010001	2^{10100}	=	1	10010011	101000100000000000000000
0.11010001	2^{-10100}	=	0	01101011	101000100000000000000000
-0.11010001	2^{-10100}	=	1	01101011	101000100000000000000000


(b) Examples




Signs for Floating Point



- ❖ Mantissa is stored in 2s compliment
- ❖ Exponent is in excess or biased notation
 - e.g. Excess (bias) 128 means
 - 8 bit exponent field
 - Pure value range 0-255
 - Subtract 128 to get correct value
 - Range -128 to +127



- ❖ FP numbers are usually normalized
- ❖ i.e. exponent is adjusted so that leading bit (MSB) of mantissa is 1
- ❖ Since it is always 1 there is no need to store it
- ❖ (c.f. Scientific notation where numbers are normalized to give a single digit before the decimal point
- ❖ e.g. 3.123×10^3)



❖ For a 32 bit number



- 8 bit exponent
- +/- $2^{256} \approx 1.5 \times 10^{77}$

❖ Accuracy


- The effect of changing lsb of mantissa
- 23 bit mantissa $2^{-23} \approx 1.2 \times 10^{-7}$
- About 6 decimal places




Expressible Numbers



(a) Twos Complement Integers




(b) Floating-Point Numbers



- ❖ Standard for floating point storage
- ❖ 32 and 64 bit standards
- ❖ 8 and 11 bit exponent respectively
- ❖ Extended formats (both mantissa and exponent) for intermediate results





- ❖ Check for zeros
- ❖ Align significands (adjusting exponents)
- ❖ Add or subtract significands
- ❖ Normalize result








- ❖ Check for zero
- ❖ Add/subtract exponents
- ❖ Multiply/divide significands (watch sign)
- ❖ Normalize
- ❖ Round
- ❖ All intermediate results should be in double length storage




Floating Point Multiplication



Floating Point Division



Required Reading



- ❖ Stallings Chapter 8
- ❖ IEEE 754 on IEEE Web site





SELESAI

